




Digital Camera adapter Lens (DCL)


Operation and safety Manual:



- Actual DCL-28 Measurement




Step-1




- Rubber piece can be fold downward
for Digital Camera (DC) connection.

Step-2



- Digital Camera (DC) and DCL-28
connecting point.

Step-3



- Make sure Digital Camera (DC)
and DCL-28 is connected tightly
by turning clockwise before
operation.

Thank you for joining William Optics family, hopefully you will be delighted it with your product, please provide us your valuable feedback so we can produce higher quality products for everyone to enjoy.

www.william-optics.com